primo

SquishSplash

Primo
149 Shaw Ave
Irvington, NJ, 07111
www.Primobaby.com
Tel: (973) 926-5900

Customer Support:
info@primobaby.com

Reccomended Age: 0-24 Months
Max Weight: 25 lbs. / 11.3 kg.
Assembled Size: 25"W x 28"L x 39"H

Model Number: PRI-353G
Made in Zhongshan China

READ ALL INSTRUCTIONS AND WARNINGS BEFORE ASSEMBLY AND USE OF PRODUCT

Bathing Safety and Water Temperature

You should always test the temperature of the water in the bath and the water filling the bath before putting baby into bath water. Typical water temperature for bathing a baby is between 90°F and 100°F (between 32.2°C and 37.8°C). You should NEVER leave a baby unattended in the bath for any reason or any amount of time.

Use the smallest quantity possible of water when bathing your child. Babies can drown in as little as 1 inch of water.

You should stop using the bath stand once your baby is attempting to stand up on their own or can already stand up in their own.

Always use the bath and bath stand on a floor that is flat and level. Do not straddle over the threshold of the bathtub or use in a curved bottom bathtub.

⚠WARNING	⚠ADVERTENCIAS
Drowning Hazard: Babies have **drowned** while using infant bath tubs and bath stands. **To prevent drowning:** • **Stay** in arm's reach of your baby. • **Never** rely on a toddler or preschooler to help your baby or alert you to trouble. Babies have drowned even with other children in or near the bath tub. • Babies can drown in as little as 1 inch of water. Use as little water as possible to bathe your baby. • Use in **empty** adult tub or sink. • Keep drain **open** in adult tub or sink. **Fall Hazard:** Babies have suffered **head injuries** falling from infant bath tubs and bath stands. **To prevent falls:** • Place tub **only** in adult tub, sink or on floor. • Never lift or carry baby in tub or bath stand.	Peligro de ahogamiento: Los bebés se han ahogado mientras usaban bañeras infantiles y en soporte de baños. **Para prevenir ahogo:** • **Este siempré** a una distancia de su bebé. • **Nunca** confíe en un niño pequeño o en edad preescolar para ayudar a su bebé o alertarlo sobre problemas. Los bebés se han ahogado incluso con otros niños dentro o cerca de la bañera. • Los bebés pueden ahogarse en 1 pulgada de agua. Use la menor cantidad de agua posible para bañar a su bebé. • Utilícelo en una tina o un fregadero **vacíos** para adultos. • Mantenga el drenaje **abierto** en la tina o el fregadero adulto. Riesgo de caídas: Los bebés han sufrido **lesiones en la cabeza** que caen de bañeras infantiles y en soporte de baños. **Para prevenir caídas:** • Coloque la tina **sólo** en una tina para adultos, un fregadero o en el piso. • **Nunca** levante ni transporte al bebé en la bañera ni en soporte de baños.

PRIMO   149 Shaw Avenue Irvington, NJ 07111   Tel: 973-926-5900   www.primobaby.com   PRI-353

1. Parts List
   A. SquishSplash Baby Bath
   B. Lower Bath Stand Frame
   C. Upper Bath Stand Frame
   D. Drain Tube
   E. Bath Stand Feet
   F. Infant Bathing Cushion
   G. Fabric Shelf

2. Bath Stand Assembly
   A. Attach all 4 Bath Stand Feet to bottom of Lower Bath Stand Frame.
   B. Connect Upper Bath Stand Frame to Lower Bath Stand Frame ensuring that all 4 safety lock buttons click into place securely.

3. Unfolding Bath Stand
   A. Open frame and place on a level floor so that all 4 non-slip feet are secure and touching floor.
   B. Press down on safety latch located on each side of lower legs of the bath stand frame near where legs cross eachother.
4. Securing SquishSplash Bath to Bath Stand
   A. Ensure that Bath Stand is fully assembled and that all parts are securely affixed to one another.
   B. Unfold Bath Stand and SquishSplash Bath.
   C. Place SquishSplash Bath in Upper Bath Stand Frame and press down to ensure bath is fully extended.
   D. Attach all 4 velcro straps to the SquishSplash legs ensuring that all straps are as tight and secure as possible on the bath legs.
5. Using Support Cushion
   A. Place cushion in bath and attach all 3 clips to rim of bath to ensure the cushion does not move while in use.
   B. To adjust the height of the cushion in the bath, roll the excess strap around the clip until you have reached the desired length and then attach clip to side of bath.
6. Draining water from the SquishSplash
   A. Attach drain tube to drain plug on the bottom of bath and place tube to drain into bath tub, bucket, or sink.
   B. Open drain plug located inside the bottom of the bath.
7. Using SquishSplash without Bath Stand
   A. Unfold each leg until you hear the leg locks click into place and ensure each leg is locked by pushing on them (legs should not move).
   B. Place bath on a flat and level surface ensuring that each leg is fully touching the floor.
8. Cleaning & Care
   A. SquishSplash Bath: Clean bath with mild soap of choice and either hang to dry or hand dry.
   B. Bath Stand: Clean with mild soap of choice and dry thoroughly before storage. Do not allow water to sit on or inside of bath stand tubes or drain tube during storage to prevent mildew.
   C. Support Cushion: Hand wash with mild soap and hang to dry. Avoid using baby oil with cushion as it may discolor the fabric. Do not machine wash or dry cushion as it may affect shape and comfort.

primo